### Application

Spring return actuator proportional 0-10V or 3-point floating modulating control of Frese OPTIMA Compact valves in heating, ventilating and air conditioning systems.

Due to the self adaption of stroke length, the actuator provides full utilization of the OPTIMA Compact valve modulation.

Can be supplied for Frese OPTIMA Compact PICV valves (DN40-DN125)



#### Features

- Spring return function, stem up or stem down version
- Self calibrating stroke up to 40 mm
- 3-point floating or 0..10 V modulating control within the same actuator
- Voltage control signal range can be selected by use of dip switches.
- Linear or EQ% characterization available on the same actuator
- Small outer dimensions
- Removable cable
- Auto zero detection
  - Feedback signal
  - IP 54 protection
  - The electronic circuit of the actuator ensures that the running time is the same, regardless of the stroke of the valve
  - Manual operation by use of hexagonal key

#### Approvals

- Conforms to: EMC directive 2004/108/EC
- Low voltage directive 2006/95/EC

CE



•


.

•

## Technical Data

Technote

Characteristics:	Motoric, modulating, spring return
Protection class:	IP 54 to EN 60529
Frequency:	50/60 Hz
Control signal:	0-10V DC or 3-point
Control signal impedance:	Min. 100 kOhm (0-10V)
Actuating force:	600N/900 N
Stroke max:	40mm
Running time: DN40-DN125	20 s (0-10V) 60 s or 300 s, (3-pos)
Ambient operating conditions:	-10°C to 50°C
Manual operation:	Hexagonal key (Included)
Cable:	Not included
Weight:	2.80 kg



## Types and Operation Data

Type [Item no.]	Valve Dimension	Function	Supply voltage	Power Consumtion	
Type-04	DN40-DN50	010 V / 3-point	24V AC +/-20% 50-60 Hz	30 VA (*50 VA)	
[53-1950]	Threaded	Stem up	24V DC +/-20%		
Type-05	DN40-DN50	010 V / 3-point	24V AC +/-20% 50-60 Hz	30 VA (*50 VA)	
[53-1951]	Threaded	Stem down	24V DC +/-20%		
Type-06 [53-1952]			24V AC +/-20% 50-60 Hz 24V DC +/-20%	30 VA (*50 VA)	
Type-07	DN50-DN125	010 V / 3-point	24V AC +/-20% 50-60 Hz	30 VA (*50 VA)	
[53-1953]	Flanged	Stem down	24V DC +/-20%		
lax consumption - for	r transformer sizing	1			


Combination matrix: Frese OPTIMA Compact DN40-125 / Actuators

Frese OPTIMA Compact DN40-125 can be combined with the following spring return actuators.		Spring return					
	Туре	Stroke	Actuator	Type-04	Type-05	Type-06	Type-07
	DN40 threaded	15	force 600	Stem up	Stem down	Stem up	Stem down
	DN50 threaded	15	600	٠	•		
	DN50 flanged	20	900			•	•
	DN65 flanged	20	900			٠	•
	DN80 flanged	20	900			٠	•
	DN100 flanged	40	900			٠	•
	DN125 flanged	40	900			•	•

www.frese.eu



### Actuator Settings



There are nine switches in a row on the circuit board. On delivery ('Factory'), all switches are in OFF" position.

#### 1 Feedback signal

Select between 2-10V and 0-5V feedback voltage output .

#### 2 Control signal — PROP/FLOAT

Actuator can either be controlled by a variable direct voltage, known as a proportional modulating signal (PROP), or by a 3-point floating signal (FLOAT).

#### 3 Sequence or parallel control — -- - / SEQ

With sequence (or parallel) control (SEQ), two actuators/valves can be controlled by only one control signal.

For each of these you can choose which part of the voltage range to use, the upper one, 5-10 V (6-10 V) or the lower one, 0-5 V (2-6 V).

If the switch NORM / INV is in the NORM position, the higher voltage corresponds to 100% flow and the lower one to 0%. With NORM / INV in the INV position you will get the opposite function.

# Note! If sequence or parallel control is not used, the switch --- / SEQ must be in the OFF position, as the switch MOD / INC is not valid during sequence or parallel control.

#### 4 Voltage range — 0-10 / 2-10

You can choose whether to use the control signal voltage range 0-10 V or 2-10 V.

#### 5 Part of voltage range — 0-5, 2-6 / 5-10. 6-10

You can choose which part of a voltage range to use, the lower one 0-5 V (2-6 V) or the upper one 5-10 V (6-10 V).

If the switch is in the NORM position, the higher voltage corresponds to 100% flow and the lower one to 0%. To achieve the opposite function, the switch should be put in its INV position.

#### 6a Running time — 60 s / 300 s

With 3-point floating control, you can choose a running time between 60 s or 300 s. With modulating control, the running time is 20 s.

#### 7 Direction of movement — NORM / INV

Actuators direction of movement according to the control signal. In normal 'NORM' mode the actuator directly follows the control signal and closes the valve downwards against a OV control signal.

In inverse 'INV' mode, the actuator reverses the direction of travel against the control signal and will open the valve upwards against a 0V control signal.

#### 8 Linearization — LIN /EQ%

The total valve characteristics can be modified from linear to EQ%.

#### 9 End position adjustment — OP / ADJ

This switch is only used to adjust the end positions when the actuator is commissioned.


Momentarily put the switch in the ON position. The actuator will automatically find the end positions of the valve.

Stroke calibration will only be initiated once power is applied to the actuator and the user has triggered this switch.






#### **Connection Diagrams**




#### Wiring Examples

#### 0-10V, 2-10V..... control signal




4 wires to the actuator




For 0-10V control with 3 wire connection, it is needed to mount an internal wiring between MX and G0

#### 3-pos control signal



Frese A/S assumes no responsibility for errors, if any, in catalogues, brochures, and other printed matter. Frese A/S reserves the right to modify its products without prior notice, including already ordered products, if this does not alter existing specifications. All registered trademarks in this material are the property of Frese A/S. All rights reserved.

#### 4-20 mA control signal



A 500  $\Omega$  resistor must be connected between X1 and MX. (Not delivered with the actuator) Dip switch 2 must be OFF and Dip switch 4 must be ON

> Frese A/S Sorøvej 8 DK- 4200 Slagelse Tel: +45 58 56 00 00 info@frese.dk

