



# Frese PV-SIGMA Compact

- DK** Montagevejledning
- DE** Montageanleitung
- EN** Mounting instructions


Danmark · Tlf. +45 58 56 00 00  
 Deutschland · Tel. +49 (0)241 475 82 333  
 UK · Tel. +44 (0)1704 896012



- DK** Skitse af varmesystem med Frese PV-SIGMA Compact
- DE** Skizze eines Heizungssystems mit Frese PV-SIGMA Compact
- EN** Outline of a heating system with Frese PV-SIGMA Compact




- DK** Differenstrykregulatoren PV Compact indstilles vha. en 4 mm sekskantnøgle, ud fra grafen for den valgte ventildimension. Den dynamiske indreguleringsventil SIGMA Compact indstilles vha. håndtaget, ud fra grafen eller fra Frese's APP.
- DE** Der Differenzdruckregler PV Compact lässt sich mit Hilfe eines 4-mm Sechskantschlüssels einstellen, anhand der Voreinstelldiagramme für die betreffende Reglergröße. Der dynamische Volumenstromregler SIGMA Compact, lässt sich mit dem Handrad einstellen, anhand der Voreinstelldiagramme oder der Frese APP.
- EN** The differential pressure control valve PV Compact is set by means of a 4mm hexagonal key, from the flow rate graphs for the valve dimension in question. The dynamic balancing valve SIGMA Compact, is set by the hand wheel, from the flow rate graphs or from the Frese APP.




- DK** Monter T-stykke i SIGMA Compact og forbind kappillarrør mellem ventilerne.
- DE** Montieren Sie das T-Stück in SIGMA Compact und verbinden Sie das Kapillarrohr zwischen den beiden Ventilen
- EN** Mount the T-piece in SIGMA Compact and connect the capillary tube between the two valves

### Frese PV-SIGMA Compact DN15 Low

Frese PV Compact DN15, 5-30 kPa




Frese SIGMA Compact DN15 Low




### Frese PV-SIGMA Compact DN15 High

Frese PV Compact DN15, 20-60 kPa




Frese SIGMA Compact DN15 High




### Frese PV-SIGMA Compact DN20 Low

Frese PV Compact DN20, 5-30 kPa




Frese SIGMA Compact DN20 Low




### Frese PV-SIGMA Compact DN20 High

Frese PV Compact DN20, 20-60 kPa




Frese SIGMA Compact DN20 High




### Frese PV-SIGMA Compact DN25 Low

Frese PV Compact DN25, 5-30 kPa




Frese SIGMA Compact DN25 High




### Frese PV-SIGMA Compact DN25 High

Frese PV Compact DN25L, 20-80 kPa




Frese SIGMA Compact DN25 High




### Frese PV-SIGMA Compact DN32

Frese PV Compact DN32, 20-80 kPa




Frese SIGMA Compact DN32




### Frese PV-SIGMA Compact DN40

Frese PV Compact DN40, 20-80 kPa




Frese SIGMA Compact DN40



### Frese PV-SIGMA Compact DN50

Frese PV Compact DN50, 20-80 kPa



Frese SIGMA Compact DN50

