

Application

Actuator, proportional 0-10 V, 4-20 mA or 2/3-point floating modulating control of OPTIMA Compact valves in heating, ventilating and air conditioning systems.

Due to the self adaption of stroke length, the actuator provides full utilization of the OPTIMA Compact valve modulation.

Can be supplied for OPTIMA Compact PICV valves (DN50-DN300)



Features

- Spring return function, stem up or stem down version
- Self calibrating
- 2/3-point floating, 4-20 mA or 0-10 V modulating control within the same actuator
- Linear or EQ% characterization available on the same actuator
- Auto zero detection
- 0-10 V feedback signal
- IP 66 protection EN60529
- Direct mounting with automatic spindle connection.
- · Manual operation by use of handle
- Auxiliary switch as accessory
- 24 V power supply as standard and 230 V power supply as accessory
- Possibility to add relay control for failsafe operation

Approvals

- Conforms to: EMC directive 2004/108/EC
- Low voltage directive 2006/95/EC
- · UL approved





Technical Data

Characteristics:Motoric, modulatingVariant:Spring ReturnProtection class:IP 66 to EN 60529

Frequency: 50/60 Hz **Supply voltage** 24 V AC/DC

230 V AC (with accessory)

Control signal: 0-10V DC, 4-20 mA DC or 3-point/2point floating

 $\textbf{Control signal impedance:} \qquad \qquad \text{Min. 100 k}\Omega \ (0\text{-}10 \ \text{V})$

Stroke max: 48 mm

Running time: 288 sec (Factory setting)


Ambient operating conditions:0 °C to 55 °CManual operation:HandleCable:Not included

Cable glands $2 \times M20 \times 1.5$ shall be used (Not included)

Weight: 4.20 kg Standard

5.90 kg Spring Return

Dimensions



Types and Operation Data


Type [Item no.]	Valve Dimension	Control signal	Function	Actuator force	Supply voltage	Power Consumption
Type-08 [53-1954]	DN50-DN200	0-10 V/4-20 mA 2/3-point	Spring Return Stem up	1100 N	24 V AC ±20% 24 V DC ±15%	10 W/ (20 VA*)
Type-09 [53-1955]	DN50-DN200	0-10 V/4-20 mA 2/3-point	Spring Return Stem down	1100 N	24 V AC ±20% 24 V DC ±15%	10 W/ (20 VA*)
Type-10 [53-1299]	DN150-DN300	0-10 V/4-20 mA 2/3-point	Standard	2500 N	24 V AC ±20% 24 V DC ±15%	10 W/ (18 VA*)
Type-11 [53-1956]	DN150-DN300	0-10 V/4-20 mA 2/3-point	Spring Return Stem up	2000 N	24 V AC ±20% 24 V DC ±15%	10 W/ (20 VA*)
Type-12 [53-1957]	DN150-DN300	0-10 V/4-20 mA 2/3-point	Spring Return Stem down	2000 N	24 V AC ±20% 24 V DC ±15%	10 W/ (20 VA*)

^{*)} Design transformer for this value




Connection Diagrams · Standard Actuator

24 V AC/DC



Connection Diagrams · Spring Return Actuator

24 V AC/DC






Connection Diagrams · Standard Actuator

230 V AC


2-position connection 3-position connection



Connection Diagrams · Spring Return Actuator

0-10 V / 4-20 mA connection


230 V AC



2-position connection 3-position connection 230 V~ 21 N 2a 2b Module 230 V~ Spring Return Spring Return




LED Indication Actuators



1 Status and acting direction indication (LED)

- The display consists of two dual-colour LEDs (red / green).
- Both LEDs flashing red: Initialisation procedure
- Upper LED lit red: Upper limit stop or "OPEN" position reached
- Lower LED lit red: Lower limit stop or "CLOSED" position reached
- Upper LED flashing green: drive running, moving towards "OPEN" position
- Upper LED lit green: drive stationary, last direction of running "OPEN"
- Lower LED flashing green: drive running, moving towards "CLOSED" position
- Lower LED lit green: drive stationary, last direction of running "CLOSED"
- No LED lit: No voltage supply (terminal 2b)
- Both LEDs are flashing red and green: drive is in manual mode

Actuator Settings





Feedback signal

When the actuator is connected according to the connection diagrams at page 3, with power supply at terminal 2b, the relation between the input signal, valve position and the feedback signal is according to the table.

Feedback signal in relation to input signal and valve position

Input signal [V]	Input signal [mA]	Valve position 100% fully open 0% fully closed [%]	Feedback signal 0-10V [V]
0	4	0	10
5	12	50	5
10	20	100	0

Accessories


Frese no.	Туре
07-2925	230V transformer
07-21301	Auxiliary switch

The transformer (07-2925) can be installed in the actuator to enable a 230 V power supply instead of a 24 V power supply.


The Auxiliary swith (07-21301) can be installed in the actuator to enable switching on/off external equipment, e.g. indication lamps or feedback to other control systems.





Mounting 230 V Transformer



Mounting & Setting Auxiliary switch







Switch over after a short stem extraction X_{51} Switch over after a longer stem extraction Switch over after a longer stem extraction X_{51} X_{52} X_{53} X_{54} X_{55} X_{55}

Please note:

Max Current: 3 A/250 V (for auxiliary switch)

Steps for installing and calibrating the auxiliary switch.

- 1. Open and remove cover plate and mount cable gland
- 2. Calibrate actuator by connecting power to the actuator after mounted on valve
- 3. Mount auxiliary switch with screw driver
- 4. Calibrate the auxiliary switch by turning the dial by a screwdriver to set the valve position, at wich relay shall switch over between the two contacts in relation to the opening/closing of the valve. s = stroke in mm.
- **s1** is typically used for providing a closed contact between terminal 4 and 5 for fully closed valve.
- **s2** for providing a closed contact between terminal 7 and 8 for fully open valve.

Please note: For precise setting of the switch over position, please use a multimeter for vertication of the resistance.

Frese A/S assumes no responsibility for errors, if any, in catalogues, brochures, and other printed matter. Frese A/S reserves the right to modify its products without prior notice, including already ordered products, if this does not alter existing specifications. All registered trademarks in this material are the property of Frese A/S. All rights reserved.

Frese A/S Tel: +45 58 56 00 00 info@frese.dk